ENGINEER'S SPECIFICATION

EPG Series L950PT PumpMasterTM Controller

1Ø CONTROL PANEL

г	mich and EDC Communication Life Life 1500 A /COO A. Coming LOSODE controlled to alternate the amounting of two
pu	rnish one EPG Companies Inc., UL listed 508A/698A, Series L950PT controller to alternate the operation of two mp motors and auxiliary equipment in manual or automatic mode. The control panel enclosure shall be NEMA be
tar	e enclosure shall be equipped with a window in the outer door, an inner door, a stainless steel drip shield, and a nper resistant latch. The NEMA 4 (standard) enclosure is finished with polyester urethane paint. The NEMA 4X ptional) enclosure can be either stainless steel or non-metallic.
	e control system will operate from a Volt, 60 Hertz, single phase power supply. Pump control mponents will be sized to operate pump motors of specified horsepower.
Th	e control panel shall include the following as standard features:
*	Main Disconnect Switch: The main disconnect switch shall be Amp rated and will prevent opening of control panel while power is on, and includes Volt, Amp dual element fuses.
*	"Hand-Off-Auto" Selector Switches: Allow manual or automatic operation. The selector switches shall be heavy duty, oil tight, NEMA 4 rated switches mounted on the inner door. The hand position shall be momentary with a spring return.
*	Motor Contactors: The motor contactors shall be sized to pump motor horsepower.
*	<u>Motor Start Winding Control with Start Capacitors and Start Winding Relays:</u> Capacitors are used to start motors. Relays are used to remove start winding from circuit when motors reach operating speed.
*	<u>Control Transformer:</u> Transformer with fused primary and secondary shall isolate control circuit from power circuit and provide easier and safer field wiring of accessories. It shall lower incoming voltage to 120 Volts.
*	<u>Run Lights:</u> Indicate energization of motor circuit. They shall be heavy duty, oil tight, NEMA 4 rated and shall have LED lamps with 100,000 hour life. The lights shall be mounted on the inner door and will be green in color.
*	<u>Electronic Alternator</u> : The electronic alternator shall include lead/lag pump operation to equalize wear on pump motors by alternating successive starts. The lag pump shall start after the lead pump starts if the liquid level continues to rise above the pump start level set point and both pumps will continue to run until the liquid level decreases to the pump stop level set point as sensed by the pressure transmitter.
*	<u>LevelMasterTM Level Control:</u> The LevelMaster level control meter shall be mounted on the inner door. The meter shall have a digital readout and the capability to monitor and maintain pumping operations as well as output a high level alarm. It shall also provide a high-high level alarm fail-safe feature that shuts off the pump motors. The high-high alarm may indicate level sensor failure or a problem with a pump(s). Level control shall be least two other level signals. Level control shall be accurate to within 0.1 inch.
*	<u>Level Simulator</u> : The level simulator shall be mounted on the inner door. The level simulator is a built-in test circuit designed to simulate a 4-20 mA load to assist in level setup and troubleshooting.
*	Intrinsically Safe Barriers: The level sensor circuits shall be by protected by intrinsically safe barriers.
*	<u>Heater with Adjustable Thermostat:</u> A heater with adjustable thermostat shall promote even distribution of heat and elimination of hot spots and condensation. Heater element shall be mounted in space between the sub-panel and the back of the enclosure and provide a minimum of inches square of heating area.
*	<u>Lightning Arrestor:</u> Shall be grounded, metal-to-metal, to water strata.

- * Terminal Strip: Labeled and numbered terminal strip provides easy connection of external components.
- * Corrosion Inhibitor Emitter: Inclusion of an industrial corrosion inhibitor emitter shall protect internal components of control panel from corrosion for up to one year and shall be replaceable.
- * Options are available to meet specific needs.

SYSTEM LOGIC AND FUNCTION

The controller is deigned to operate two pumps in lead/lag alternating mode. The electric alternator provides equalized wear and usage of each pump by alternating successive starts. The lead pump starts at the pump start level set point and continues to run until the liquid level decreases to the pump stop level set point as programmed in the LevelMaster level control meter. The lag pump will start after the lead pump starts if the liquid level continues to rise above the pump start level set point and both pumps will continue to run until the liquid level decreases to the pump stop level set point as sensed by the pressure transmitter. If the liquid level rises to the high level alarm set point, a high level alarm will be annunciated. If the liquid level rises to the high-high level fail-safe set point, the pumps will shut off. If a motor trips while running due to an overload condition, the other pump will start automatically. The pressure transmitter level sensor shall have a range of 0 ______ feet with a 4-20 mA output signal.